

Figure 2. The tone control (mono) circuit




Figure 3. Connections

NEW KIT SET

| CODE FK | DESCRIPTION | POWER |
|---------|---|-------------|
| 168 | NO SMOKING FLASHER 46 LED | 9-12VDC. |
| 169 | DANCING ROBOT FLASHER 33 LED | 9-12VDC. |
| 170 | DANGER FLASHER 42 LED | 9-12VDC. |
| 171 | TWO LAMP FLASHER | 3VDC. |
| 172 | THREE STEP FLASHER 19 LED | 9-12VDC. |
| 173 | HALLOWEEN PUMPKIN FLASHER 23 LED | 9-12VDC. |
| 174 | 5x7 ANIMATED LED SIGNBOARD | 3-5VDC. |
| 816 | VARIABLE REGULATOR 0-50V. 3A. | 50VDC. |
| 817 | TRANSFORMERLESS POWER SUPPLY 6-9-12V 50mA | 220-240VAC. |